



Original	Replacement
Speakers TV Audio Bravia Sync	Shift + Sound / Title
Power AV Bravia Sync	Shift + Power
Power	Power
1	1
2	2
3	3
4	4
5	5
6	6
7	7
8	8
9	9
♥	Fav / Marker / PC
[≡]	Text / Goto
0	0
Enter	Guide / EPG / -/--
Red	Red / Netflix / Search

Original	Replacement
Green	Green / APP / Repeat
Yellow	Yellow / YouTube / Repeat
Blue	Blue / Prime Video / Random
Top Menu	D.Menu / Top
Up	Up
Left	Left
OK	OK
Right	Right
Return	Back / Return
Down	Down
Options	Setup / OPT /
Home/Menu	Menu / Home
Sound Mode	Sound / Title
I<</Preset-	I<< / Preset-
←	Shift + Left
→	Shift + Right
>>I/Preset+	>>I / Preset+





Original		Replacement		Original	Replacement
	<</Tuning-		<< / Tune-		
	Play		Play / Slow		
	>>/Tuning+		>> / Tune+		
	[...]		Subtitle / EQ		
	Pause		Pause / Step / Freeze		
	Stop		Stop / Hold		
	Mute		Mute / Dimmer		
	Vol+		Vol+		
	Prog+		CH+ / Page+		
	Display		Display / Media		
	O)))		Audio / Lang I/II		
	Vol-		Vol-		
	Prog-		CH- / Page-		
	Sleep		Sleep / Timer		





Original	Replacement	Original	Replacement
	Eject / Surround		Blue / Prime Video / Random
	Power		D.Menu / Top
	1		Up
	2		Smart / List
	3		Left
	4		OK
	5		Right
	6		Back / Return
	7		Down
	8		Setup / OPT /
	9		Info / Angle
	Fav / Marker / PC		Menu / Home
	0		Sound / Title
	Guide / EPG / -/--		I<< / Preset-
	Red / Netflix / Search		Shift + Left
	Green / APP / Repeat		Shift + Right
	Yellow / YouTube / Repeat		>>I / Preset+





Original	Replacement	Original	Replacement
 <</Tuning-	 << / Tune-		
 Play	 Play / Slow		
 >>/Tuning+	 >> / Tune+		
 [...]	 Subtitle / EQ		
 Pause	 Pause / Step / Freeze		
 Stop	 Stop / Hold		
 Mute	 Mute / Dimmer		
 Vol+	 Vol+		
 Display	 Display / Media		
 O)))	 Audio / Lang I/II		
 Vol-	 Vol-		
 Sleep	 Sleep / Timer		





Original	Replacement
Speakers TV Audio Bravia Sync	Sound / Title
Power AV Bravia Sync	Shift + Power
Power	Power
1	1
2	2
3	3
4	4
5	5
6	6
7	7
8	8
9	9
♥ Fav / Marker / PC	Fav / Marker / PC
[≡] Text / Goto	Text / Goto
0	0
Red	Red / Netflix / Search
Green	Green / APP / Repeat

Original	Replacement
Yellow	Yellow / YouTube / Repeat
Blue	Blue / Prime Video / Random
Top Menu	D.Menu / Top
Up	Up
Left	Left
OK	OK
Right	Right
Return	Back / Return
Down	Down
Home/Menu	Menu / Home
[...]	Subtitle / EQ
Mute	Mute / Dimmer
Vol+	Vol+
Prog+	CH+ / Page+
Display	Display / Media
Vol-	Vol-
Prog-	CH- / Page-



