







































































Original	Replacement
 Power	 Power
 TV / AV	 AV
 Open / Close	 Eject
 Multimedia	 Media
 List	 List
 [=] / Text	 Text
 PSM	 Shift + Format
 SSM	 Shift + Dual
 I/II / Audio	 Dual
 Stop	 Stop
 Play	 Play
 Pause / Step	 Pause
 I<<	 I<<
 >>I	 >>I
 <<	 <<
 >>	 >>
 >I< / Repeat	 Shift + Text

Original	Replacement
 Menu	 Menu
 ARC	 Back
 Exit	 Exit
 Up	 Up
 Down	 Down
 Right	 Right
 Left	 Left
 OK	 Ok
 Red / Disc Menu	 Red
 Green / Title	 Green
 Yellow / Display	 Yellow
 Blue / Return	 Blue
 Vol +	 Vol +
 Vol -	 Vol -
 Mute	 Mute
 PR +	 Ch +
 PR -	 Ch -





Original	Replacement
 Q.View	 Options
 1	 1
 2	 2
 3	 3
 4	 4
 5	 5
 6	 6
 7	 7
 8	 8
 9	 9
 0	 0
 Sleep	 Sleep
 Clear	 Shift + Exit
 A-B	 3D
 Random	 Smart
 Angle	 Shift + Info
 Sub.T	 Subt

Original	Replacement
 Marker	 Shift + Media
 Search	 TV/R
 Program	 Shift + Sleep
 Zoom	 Shift + Eject
 [=o] / Time	 Shift + AV
 [= / ] / Mix	 Pre Ch
 [=?] / Reveal	 Guide
 [=M] / Mode	 D. Menu
 [=X] / Update	 Shift + TV/R
 [=♦] / Size	 Format
 [=+] / Hold	 Shift + Subt
 [=i] / Index	 Info

