









































































































Original	Replacement	Original	Replacement
 Power	 Power	 [=+]/Repeat	 Shift + Text
 1	 1	 Scan >>	 >>
 2	 2	 << Scan	 <<
 3	 3	 << Skip	 <<
 4	 4	 >> Skip	 >>
 5	 5	 Play	 Play
 6	 6	 Stop	 Stop
 7	 7	 Pause/Step	 Pause
 8	 8	 Menu/List	 Menu
 9	 9	 [=]	 List
 0	 0	 Home	 Smart
 Tv/DVD	 TV/R	 Guide	 Guide
 Open/Close	 Eject	 Return	 Back
 Display	 Info	 Red/FAV	 Red
 Text	 Text	 Green/Audio	 Green
 Rec	 Rec	 Yellow/Subtitle	 Yellow
 [=i]/Zoom	 Format	 Blue/Timeshift	 Blue





Original	Replacement
 Enter	 Ok
 Up	 Up
 Down	 Down
 Right	 Right
 Left	 Left
 PR-	 Ch -
 PR+	 Ch +
 DVD	 D. Menu
 HDD	 Media
 Clear	 Exit
 Dubbing	 Subt
 Search	 Shift + TV/R
 Title	 Sleep
 Thumbnail	 Options
 Random	 Shift + Dual
 CHP.ADD	 Shift + Subt
 PIP	 3D

Original	Replacement
 Showview	 Pre Ch
 Resolution	 Shift + Format
 Power Tv	 Shift + Power
 AV Tv	 Shift + AV
 PR+ TV	 Shift + Ch +
 PR- Tv	 Shift + Ch -
 Mute Tv	 Mute
 Vol+ Tv	 Vol +
 Vol- Tv	 Vol -
 AV	 AV
 Marker	 Dual

