







































































































Original		Replacement		Original		Replacement	
	Power		Power		9		9
	CH.List		List		0		0
	Tv/Radio		TV/R		Info		Info
	FAV		Pre Ch		Recall		Back
	Sleep		Sleep		Freeze		Pause
	Input		AV		Guide		Guide
	Sound		Shift + Dual		I/II/Audio Lang		Dual
	Picture		Shift + Format		Vol+		Vol +
	Aspect		3D		Vol-		Vol -
	1		1		Mute		Mute
	2		2		Prog+		Ch +
	3		3		Prog/Page-		Ch -
	4		4		Up		Up
	5		5		Down		Down
	6		6		Right		Right
	7		7		Left		Left
	8		8		OK		Ok





Original	Replacement	Original	Replacement
 Menu	 Menu		
 Exit	 Exit		
 Red	 Red		
 Green	 Green		
 Yellow	 Yellow		
 Blue	 Blue		
 Index	 Shift + Info		
 Hold	 Options		
 Text	 Text		
 Size	 Format		
 Subtitle	 Subt		
 Mix	 Media		
 Reveal	 Smart		
 Cancel	 Eject		
 Time	 Shift + AV		
 Subpage	 D. Menu		

