

































































































| Original                                                                                      | Replacement                                                                                             |
|-----------------------------------------------------------------------------------------------|---------------------------------------------------------------------------------------------------------|
|  Standby/on  |  Power                 |
|  Open/close  |  Eject / Surround      |
|  CD          |  Shift + 3             |
|  USB         |  Shift + 8             |
|  Tuner       |  Shift + 6             |
|  Audio In    |  Audio / Lang I/II     |
|  BT Audio    |  Shift + 9             |
|  Clock/Timer |  Shift + Sleep / Timer |
|  Sleep       |  Sleep / Timer         |
|  1           |  1                     |
|  2          |  2                    |
|  3         |  3                   |
|  Equalizer |  Setup / OPT /       |
|  4         |  4                   |
|  5         |  5                   |
|  6         |  6                   |
|  P.Bass    |  Sound / Title       |

| Original                                                                                             | Replacement                                                                                                     |
|------------------------------------------------------------------------------------------------------|-----------------------------------------------------------------------------------------------------------------|
|  7                |  7                           |
|  8                |  8                           |
|  9                |  9                           |
|  Bass/Treble      |  Shift + Sound / Title       |
|  Clear            |  Exit / Cancel / Clear       |
|  0                |  0                           |
|  Repeat           |  Green / APP / Repeat        |
|  Random           |  Blue / Prime Video / Random |
|  Display          |  Display / Media             |
|  Up/Tune+         |  Up                          |
|  Folder          |  Text / Goto                |
|  Left           |  Left                      |
|  Enter          |  OK                        |
|  Right          |  Right                     |
|  Menu           |  Menu / Home               |
|  Down/Tune-     |  Down                      |
|  Memory/Program |  TV/Radio /                |





|                                                                                     | Original    | Replacement                                                                                                                                                                                         | Original | Replacement |
|-------------------------------------------------------------------------------------|-------------|-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|----------|-------------|
|    | Preset+     |  >>  / Preset+                                                                                                     |          |             |
|    | Mute        |  Mute / Dimmer                                                                                                     |          |             |
|    | Vol+        |  Vol+                                                                                                              |          |             |
|    | Preset-     |   << / Preset-                                                                                                     |          |             |
|    | Dimmer      |  +  Shift + Mute / Dimmer         |          |             |
|    | Vol-        |  Vol-                                                                                                              |          |             |
|    | << /<<      |  << / Tune-                                                                                                        |          |             |
|    | Stop        |  Stop / Hold                                                                                                       |          |             |
|    | Play        |  Play / Slow                                                                                                       |          |             |
|   | Pause       |  Pause / Step / Freeze                                                                                            |          |             |
|  | >> />>      |  >> / Tune+                                                                                                      |          |             |
|  | ST/Mono     |  +  Shift + Audio / Lang I/II |          |             |
|  | RDS ASPM    |  +  Shift + Smart / List      |          |             |
|  | RDS PTY     |  Smart / List                                                                                                    |          |             |
|  | RDS Display |  +  Shift + Display / Media   |          |             |
|                                                                                     |             |                                                                                                                                                                                                     |          |             |
|                                                                                     |             |                                                                                                                                                                                                     |          |             |

