







































































| Original | Replacement | Original | Replacement |
|--|---|--|--|
|  Power |  Power |  3D |  Shift + 3 |
|  1 |  1 |  ? |  Display / Media |
|  2 |  2 |  @ |  Info / Angle |
|  3 |  3 |  Menu |  Menu / Home |
|  4 |  4 |  Up |  Up |
|  5 |  5 |  ← |  Back / Return |
|  6 |  6 |  Left |  Left |
|  7 |  7 |  OK |  OK |
|  8 |  8 |  Right |  Right |
|  9 |  9 |  Tools |  Setup / OPT / |
|  FAV |  Fav / Marker / PC |  Down |  Down |
|  0 |  0 |  Guide |  Guide / EPG / -/-- |
|  TXT |  Text / Goto |  Vol+ |  Vol+ |
|  Red |  Red / Netflix / Search |  Source |  AV / Input / RDS |
|  Green |  Green / APP / Repeat |  P+ |  CH+ / Page+ |
|  Yellow |  Yellow / YouTube / Repeat |  Vol- |  Vol- |
|  Blue |  Blue / Prime Video / Random |  Mute |  Mute / Dimmer |



