




















































































| Original  |                   | Replacement   |               | Original  |              | Replacement   |         |
|---|-------------------|---|---------------|---|--------------|---|---------|
|    | Power             |    | Power         |    | 1            |    | 1       |
|    | Power Tv          |    | Shift + Power |    | 2            |    | 2       |
|    | Open/Close        |    | Eject         |    | 3            |    | 3       |
|    | Theatre Sync      |    | Smart         |    | 4            |    | 4       |
|    | Tv Input          |    | AV            |    | 5            |    | 5       |
|    | Tv CH+            |    | Ch +          |    | 6            |    | 6       |
|    | Tv CH-            |    | Ch -          |    | 7            |    | 7       |
|    | Display           |    | Info          |    | 8            |    | 8       |
|    | Function          |    | Options       |    | 9            |    | 9       |
|    | Disc Skip         |    | Media         |    | 0            |    | 0       |
|   | Sound Field       |   | Red           |   | Clear        |   | Exit    |
|  | Movie/Music       |  | Green         |  | System Menu  |  | Menu    |
|  | Dynamic Bass      |  | Yellow        |  | Muting       |  | Mute    |
|  | Video Format      |  | Blue          |  | Picture Navi |  | List    |
|  | Audio             |  | Dual          |  | Vol+         |  | Vol +   |
|  | Subtitle/D.Tuning |  | Subt          |  | Vol-         |  | Vol -   |
|  | Angle             |  | Text          |  | DVD Menu     |  | D. Menu |





| Original  | Replacement   |
|---|---|
|  Menu TV   |  Shift + D. Menu |
|  -/-- Tv   |  Guide           |
|  10/0 Tv   |  Shift + 0       |
|  Return Tv |  Shift + Back    |
|  1 Tv      |  Shift + 1       |
|  2 Tv      |  Shift + 2       |
|  3 Tv      |  Shift + 3       |
|  4 Tv      |  Shift + 4       |
|  5 Tv      |  Shift + 5       |
|  6 Tv      |  Shift + 6       |
|  7 Tv     |  Shift + 7      |
|  8 Tv    |  Shift + 8     |
|  9 Tv    |  Shift + 9     |
|  OK      |  Ok            |
|  Return  |  Back          |
|  Up      |  Up            |
|  Down    |  Down          |

| Original  | Replacement   |
|---|---|
|  Right           |  Right         |
|  Left            |  Left          |
|  Tv Vol+         |  Shift + Vol + |
|  Tv Vol-         |  Shift + Vol - |
|  Up Tv           |  Shift + Up    |
|  Down Tv         |  Shift + Down  |
|  Right Tv        |  Shift + Right |
|  Left Tv         |  Shift + Left  |
|  [ ]/Display     |  3D            |
|  Play            |  Play          |
|  Pause          |  Pause        |
|  Stop          |  Stop        |
|  >>/>/Tuning + |  >>          |
|  <</</Tuning - |  <<          |
|  >>/>/Preset+  |  >>I         |
|  I<</</Preset- |  I<<         |
|  OK Tv         |  Shift + Ok  |





