



Original	Replacement	Original	Replacement
 Power	 Power	 0	 0
 Repeat	 Text	 10+	 Guide
 A-B	 Shift + Text	 Time	 AV
 Open / Close	 Eject	 Setup	 Options
 N / P	 TV/R	 Title	 Media
 Subtitle	 Subt	 Up	 Up
 Angle	 Format	 Right	 Right
 Language	 Dual	 Down	 Down
 1	 1	 Left	 Left
 2	 2	 Enter	 Ok
 3	 3	 PBC	 Smart
 4	 4	 Menu	 Menu
 5	 5	 Vol -	 Vol -
 6	 6	 Vol +	 Vol +
 7	 7	 Zoom	 Shift + Eject
 8	 8	 Return	 Back
 9	 9	 L / R	 Shift + Dual



