



Original	Replacement
 Standby/On	 Power
 1/5Beam	 1
 2/ST+3Beam	 2
 3/3Beam	 3
 4/Stereo	 4
 5/My Beam	 5
 6/My Sur.	 6
 +10	 Guide
 Sur Decode	 Pre Ch
 Vol+	 Vol +
 Vol-	 Vol -
 CH Level	 Info
 Menu	 Menu
 Test	 Exit
 Return	 Back
 Up	 Up
 Enter	 Ok

Original	Replacement
 Down	 Down
 Right	 Right
 Left	 Left
 Tv Vol+	 Shift + Vol +
 Tv Vol-	 Shift + Vol -
 Tv Mute	 Shift + Mute
 Mute	 Mute
 Tv Input	 AV
 << DVD	 <<
 Stop DVD	 Stop
 >> DVD	 >>
 I<< DVD	 I<<
 >>I DVD	 >>I
 Pause DVD	 Pause
 Play DVD	 Play
 Power AV DVD	 Shift + Power
 VCR	 Green





Original	Replacement
TV	TV/R
DVD	Blue
STB	Yellow
AUX	Red
Tv Input 1	List
Tv Input 2	Dual
Vol Mode	Subt
Auto Setup	Options
Input Mode	Format
Sleep	Sleep
Power TV	Media
Power AV VCR	Smart
CH+ VCR	Ch +
CH- VCR	Ch -
Stop VCR	Shift + Stop
Pause VCR	Shift + Pause
Play VCR	Shift + Play

Original	Replacement
>> VCR	Shift + >>
Stop Tv	Shift + Left
<< VCR	Shift + <<
Pause Tv	Shift + Right
Power AV AUX	Shift + Smart
Play Tv	Shift + Ok
CH+ AUX	Shift + Ch +
CH- AUX	Shift + Ch -
CH+ Tv	Shift + Up
CH- Tv	Shift + Down
<< Tv	Shift + I<<
>> Tv	Shift + >>I
I<< Tv	Text
>>I Tv	3D





Original	Replacement
 Power Tv	 Power
 Standby/On	 Shift + Power
 AUX	 Red
 Vol Mode	 Subt
 Auto Setup	 Options
 Input Mode	 Format
 Sleep	 Sleep
 1	 1
 2	 2
 3	 3
 4	 4
 5	 5
 6	 6
 7	 7
 8	 8
 9	 9
 0	 0

Original	Replacement
 +10	 Guide
 Sur Decode	 Pre Ch
 CH Level	 Info
 Menu	 Menu
 Test	 Exit
 Return	 Back
 Up	 Up
 Down	 Down
 Right	 Right
 Left	 Left
 Enter	 Ok
 CH+	 Ch +
 CH-	 Ch -
 Tv Vol+	 Vol +
 Tv Vol-	 Vol -
 Tv Mute	 Mute
 Tv Input	 AV



