



Original		Replacement		Original	Replacement
	Power		On		
	Power		OFF		
	Vol -		Vol -		
	Vol -		KS Down		
	Point		1 / Point		
	Vol +		Vol +		
	Vol +		KS Up		
	Up		Up		
	Down		Down		
	Right		Right		
	Left		Left		
	OK		OK		
	Back		Exit / Lamp		
	Menu		Menu / Info		
	3D		3		
	Home		Auto / Mode		
	Settings		Aspect / Re-Sync		

