



Original	Replacement	Original	Replacement
Standby	Power	Green/Smart	Green
1	1	Yellow/Lock	Yellow
2	2	Blue/Sleep	Blue
3	3	Menu	Menu
4	4	Teletext	Text
5	5	P+	Ch +
6	6	P-	Ch -
7	7	Up	Up
8	8	Down	Down
9	9	Right	Right
0	0	Left	Left
P<P	Pre Ch	OK	Ok
Clear	Exit	Vol+	Vol +
Mute	Mute	Vol-	Vol -
Record	Rec	>I/ Index	Format
Timer	AV	>I/</ Still	3D
Red/Select	Red	<<	<<



