







































































Original	Replacement	Original	Replacement
 Power	 Power	 MTS	 Options
 Mute	 Mute	 Aspect	 3D
 1	 1	 FAV/List	 Pre Ch
 2	 2	 Media	 Media
 3	 3	 Freeze	 Eject
 4	 4	 Vol+	 Vol +
 5	 5	 Vol-	 Vol -
 6	 6	 CH+	 Ch +
 7	 7	 CH-	 Ch -
 8	 8	 Menu	 Menu
 9	 9	 Source	 AV
 0	 0	 Exit	 Exit
 DTV/ATV	 Smart	 Display	 Info
 Back	 Back	 Up	 Up
 P.Mode	 Shift + Format	 Down	 Down
 S.Mode	 Dual	 Right	 Right
 Sleep	 Sleep	 Left	 Left





Original		Replacement		Original		Replacement	
	Enter		Ok		Text		Text
	Red		Red				
	Green		Green				
	Yellow		Yellow				
	Blue		Blue				
	<<		<<				
	Play		Play				
	Pause		Pause				
	>>		>>				
	I<</Cancel		I<<				
	>>I/SubPg		>>I				
	Stop/Index		Stop				
	Tv/Radio		TV/R				
	Subtitle		Subt				
	Size		Format				
	Reveal		List				
	Hold		D. Menu				

