












































Original	Replacement
 Power	 Power
 Tv/Av	 AV
 Tv/Radio	 TV/R
 Freeze	 Pause
 Info	 Info
 FAV	 Pre Ch
 [↔]	 Format
 Scan	 Smart
 1	 1
 2	 2
 3	 3
 4	 4
 5	 5
 6	 6
 7	 7
 8	 8
 9	 9

Original	Replacement
 0	 0
 ←PR	 Back
 Mute	 Mute
 Exit	 Exit
 Menu	 Menu
 EPG	 Guide
 OK	 Ok
 Up	 Up
 Down	 Down
 Right	 Right
 Left	 Left
 Red	 Red
 Green	 Green
 Position	 3D
 Yellow	 Yellow
 Text	 Text
 Blue	 Blue





Original		Replacement		Original		Replacement	
	Audio		Dual				
	Audio L/R		Subt				
	↑		Ch +				
	↓		Ch -				

