



	Original	Replacement		Original	Replacement
	Power		Power		Stop
	Vol+		Vol +		123#
	Vol-		Vol -		Rakuten Tv
	Home		Smart		Netflix
	P+		Ch +		YouTube
	P-		Ch -		
	Guide		Guide		
	Input		AV		
	Back		Back		
	Exit		Exit		
	Up		Up		
	Down		Down		
	Right		Right		
	Left		Left		
	OK		Ok		
	Colors		Red		
	Play		Play		

