















































Original	Replacement
 Power	 Power
 TV	 TV/R
 1	 1
 2	 2
 3	 3
 4	 4
 5	 5
 6	 6
 7	 7
 8	 8
 9	 9
 0	 0
 Fav CH	 Shift + Pre Ch
 Pre Ch	 Pre Ch
 Info	 Info
 Menu	 Menu
 Guide	 Guide

Original	Replacement
 Tools	 Options
 Return	 Back
 Up	 Up
 Right	 Right
 Down	 Down
 Left	 Left
 Enter	 Ok
 Internet	 Smart
 Exit	 Exit
 Red	 Red
 Green	 Green
 Yellow	 Yellow
 Blue	 Blue
 Vol +	 Vol +
 Vol -	 Vol -
 Source	 AV
 Mute	 Mute





Original		Replacement		Original	Replacement
	P +		Ch +		
	P -		Ch -		
	TTX / MIX		Text		
	Media.P		Media		
	Content		Shift + Smart		
	CH List		List		
	AD		Shift + Subt		
	Subt.		Subt		
	<<		<<		
	<<		I<<		
	Pause		Pause		
	>>		>>		
	>>		>>I		
	Rec		Rec		
	Play		Play		
	Stop		Stop		

