



Original		Replacement		Original		Replacement	
	Power		Power		Info		Info
	Sleep		Sleep		Option		Options
	CBL/SAT		1		Back		Back
	Blu-ray		2		Setup		Menu
	DVD/Blu-ray		3		Up		Up
	Game		4		Down		Down
	Tv Audio		5		Right		Right
	Media Player		6		Left		Left
	Bluetooth		7		Enter		Ok
	AM		8		CH Level		Dual
	FM		9		Mode		Subt
	CH+		Ch +		Memory		Pre Ch
	CH-		Ch -		I<</Tune-		I<<
	Eco		3D		Play		Play
	Vol+		Vol +		Pause		Pause
	Vol-		Vol -		Tune+ />>I		>>I
	Mute		Mute		Quick Select 1		Red





	Original	Replacement		Replacement
	Quick Select 2		Green	
	Quick Select 3		Yellow	
	Quick Select 4		Blue	
	< Sound Mode		<<	
	Sound Mode >		>>	
	Audio Delay+		Smart	
	Audio Delay-		Media	

	Original	Replacement

