






Original	Replacement
 Power	 Power
 D/A Input	 Shift + AV
 Tv/Radio	 TV/R
 Input	 AV
 Bright -	 Shift + Left
 Bright +	 Shift + Right
 Simplink	 Media
 Text	 Text
 Info	 Info
 Live TV	 Shift + Smart
 Red	 Red
 Green	 Green
 Yellow	 Yellow
 Blue	 Blue
 Stop	 Stop
 Play	 Play
 Pause	 Pause

Original	Replacement
 Rec	 Rec
 I<<	 I<<
 <<	 <<
 >>	 >>
 >>I	 >>I
 Back	 Back
 DVR	 Smart
 Menu	 Menu
 Exit	 Exit
 Guide	 Guide
 Up	 Up
 Right	 Right
 Down	 Down
 Left	 Left
 OK	 Ok
 Vol+	 Vol +
 Vol-	 Vol -



















































Original	Replacement
FAV	Pre Ch
Mute	Mute
PR+	Ch +
PR-	Ch -
1	1
2	2
3	3
4	4
5	5
6	6
7	7
8	8
9	9
0	0
List	List
Q.View	D. Menu
[≡x]/Update	Eject

Original	Replacement
[≡i]/Index	Shift + Info
[≡o]/Time	Shift + Exit
Sleep	Sleep
[≡+]/Hold	3D
[≡?]/Reveal	Options
Subtitle	Subt
Ratio	Format
I/II	Dual










































Original		Replacement		Original		Replacement	
	Power		Power		4		4
	Stop		Stop		5		5
	Play		Play		6		6
	Pause		Pause		7		7
	I<<		I<<		8		8
	>>		>>		9		9
	>>I		>>I		0		0
	Menu		Menu				
	Up		Up				
	Down		Down				
	Right		Right				
	Left		Left				
	OK		Ok				
	1		1				
	2		2				
	3		3				





	Original	Replacement		Original	Replacement
	Power		Power		8
	Input		AV		9
	Stop		Stop		0
	Play		Play		
	Pause		Pause		
	Rec		Rec		
	<<		<<		
	>>		>>		
	PR+		Ch +		
	PR-		Ch -		
	1		1		
	2		2		
	3		3		
	4		4		
	5		5		
	6		6		
	7		7		

