







































































Original	Replacement	Original	Replacement
 Power	 Power	 7	 7
 Mute	 Mute / Dimmer	 8	 8
 Audio	 Audio / Lang I/II	 9	 9
 TV / STB	 AV / Input / RDS	 0	 0
 TV / R	 TV/Radio /	 SAT	 Shift + 0
 Sleep	 Sleep / Timer	 EPG	 Guide / EPG / -/-
 SUB	 Subtitle / EQ	 Fav	 Fav / Marker / PC
 TXT	 Text / Goto	 PGUP	 CH+ / Page+
 Multi	 Display / Media	 PGDN	 CH- / Page-
 P / N	 Picture / Format	 Up	 Up
 Recall	 Back / Return	 Right	 Right
 1	 1	 FAV +	 Vol+
 2	 2	 FAV -	 Vol-
 3	 3	 Down	 Down
 4	 4	 Left	 Left
 5	 5	 OK	 OK
 6	 6	 Menu	 Menu / Home





Original	Replacement
	Exit / Cancel / Clear
	Red / Netflix / Search
	Green / APP / Repeat
	Yellow / YouTube / Repeat
	Blue / Prime Video / Random
	Pause / Step / Freeze
	Zoom / Size
	D.Menu / Top
	Info / Angle
	Shift + 8
	Shift + Yellow / YouTube /
	Shift + Text /
	Shift + 1
	Shift + 2
	Eject / Surround
	Stop / Hold
	Rec / Rec Mode

Original	Replacement
	Sound / Title
	<< / Tune-
	>> / Tune+
	Smart / List
	Play / Slow
	I<< / Preset-
	>I< / Setup / OPT /
	>>I / Preset+

