







































































Original	Replacement	Original	Replacement
 Power	 Power	 Pause / Step	 Pause
 Open / Close	 Eject	 I<< Prev	 I<<
 Input	 AV	 >>I Next	 >>I
 DVD	 Smart	 Stop	 Stop
 VCR	 Media	 << Rew	 <<
 TV / VCR	 TV/R	 Play	 Play
 Setup	 Menu	 >> FFW	 >>
 Disc Menu	 D. Menu	 1	 1
 Up / PR/TRK +	 Up	 2	 2
 Up / PR/TRK +	 Ch +	 3	 3
 Down / PR/TRK -	 Down	 4	 4
 Down / PR/TRK -	 Ch -	 5	 5
 Right	 Right	 6	 6
 Left	 Left	 7	 7
 OK	 Ok	 8	 8
 Display	 Info	 9	 9
 Back	 Back	 0	 0







Original	Replacement	Original	Replacement
	Power		Power
	Open / Close		Eject
	Input		AV
	DVD		Smart
	VCR		Media
	TV / VCR		TV/R
	Setup		Menu
	Up / PR/TRK +		Up
	Up / PR/TRK +		Ch +
	Down / PR/TRK -		Down
	Down / PR/TRK -		Ch -
	Right		Right
	Left		Left
	OK		Ok
	Display		Info
	Pause / Step		Pause
	Stop		Stop
	<< Rew		<<
	Play		Play
	>> FFW		>>
	1		1
	2		2
	3		3
	4		4
	5		5
	6		6
	7		7
	8		8
	9		9
	0		0
	Clear		Exit
	Marker		Pre Ch
	Record		Rec
	Search		Shift + TV/R



