







Original	Replacement
	Smart / List
	Text / Goto
	Display / Media
	Power
	Mute / Dimmer
	1
	2
	3
	4
	5
	6
	7
	8
	9
	0
	Back / Return
	Fav / Marker / PC

Original	Replacement
	Subtitle / EQ
	Info / Angle
	Picture / Format
	Vol+
	Shift + CH+ /
	CH+ / Page+
	Vol-
	Shift + CH- /
	CH- / Page-
	Audio / Lang I/II
	Shift + Audio / Lang I/II
	Sound / Title
	Guide / EPG / -/-
	Up
	Left
	OK
	Right





Original	Replacement
	Menu / Home
	Down
	Exit / Cancel / Clear
	Red / Netflix / Search
	Green / APP / Repeat
	Yellow / YouTube / Repeat
	Blue / Prime Video / Random
	Play / Slow
	Pause / Step / Freeze
	Stop / Hold
	Rec / Rec Mode
	<< / Tune-
	>> / Tune+
	<< / Preset-
	>> / Preset+
	Sleep / Timer
	Zoom / Size

Original	Replacement

