







































































| Original | | Replacement | | Original | | Replacement | |
|---|---------------|---|--------------|---|---------------|---|--------|
|  | Power |  | Power |  | Right / Vol + |  | Vol + |
|  | SUB-T |  | Subt |  | Left / Vol - |  | Left |
|  | Lang |  | Dual |  | Left / Vol - |  | Vol - |
|  | Mute |  | Mute |  | OK |  | Ok |
|  | EPG |  | Guide |  | FAV |  | Pre Ch |
|  | Goto |  | Smart |  | TV / Radio |  | TV/R |
|  | Page + |  | Shift + Ch + |  | Recall |  | Back |
|  | Page - |  | Shift + Ch - |  | Info |  | Info |
|  | TTX |  | Text |  | 1 |  | 1 |
|  | Repeat |  | Shift + Text |  | 2 |  | 2 |
|  | Menu |  | Menu |  | 3 |  | 3 |
|  | Exit |  | Exit |  | 4 |  | 4 |
|  | Up / CH + |  | Up |  | 5 |  | 5 |
|  | Up / CH + |  | Ch + |  | 6 |  | 6 |
|  | Down / CH - |  | Down |  | 7 |  | 7 |
|  | Down / CH - |  | Ch - |  | 8 |  | 8 |
|  | Right / Vol + |  | Right |  | 9 |  | 9 |









































































| Original | | Replacement | | Original | | Replacement | |
|---|-------------------|---|--------|----------|--|-------------|--|
|  | 0 |  | 0 | | | | |
|  | << |  | << | | | | |
|  | >> |  | >> | | | | |
|  | << |  | << | | | | |
|  | >> |  | >> | | | | |
|  | Play |  | Play | | | | |
|  | Pause / Timeshift |  | Pause | | | | |
|  | Stop |  | Stop | | | | |
|  | Rec |  | Rec | | | | |
|  | Red / PVR |  | Red | | | | |
|  | Green / V-Format |  | Green | | | | |
|  | Green / V-Format |  | Format | | | | |
|  | Yellow / Aspect |  | Yellow | | | | |
|  | Yellow / Aspect |  | 3D | | | | |
|  | Blue / Timer |  | Blue | | | | |
| | | | | | | | |
| | | | | | | | |





| Original | | Replacement | | Original | | Replacement | |
|---|---------------|---|-------|---|------------|---|--------|
|  | Power |  | Power |  | OK |  | Ok |
|  | Mute |  | Mute |  | FAV |  | Pre Ch |
|  | EPG |  | Guide |  | TV / Radio |  | TV/R |
|  | Info |  | Info |  | Text |  | Text |
|  | Audio |  | Dual |  | Goto |  | Smart |
|  | Recall |  | Back |  | 1 |  | 1 |
|  | Subtitle |  | Subt |  | 2 |  | 2 |
|  | Menu |  | Menu |  | 3 |  | 3 |
|  | Exit |  | Exit |  | 4 |  | 4 |
|  | Up / CH + |  | Up |  | 5 |  | 5 |
|  | Up / CH + |  | Ch + |  | 6 |  | 6 |
|  | Down / CH - |  | Down |  | 7 |  | 7 |
|  | Down / CH - |  | Ch - |  | 8 |  | 8 |
|  | Right / Vol + |  | Right |  | 9 |  | 9 |
|  | Right / Vol + |  | Vol + |  | 0 |  | 0 |
|  | Left / Vol - |  | Left |  | USB |  | Media |
|  | Left / Vol - |  | Vol - |  | Rec |  | Rec |





| Original | Replacement | Original | Replacement |
|--|---|----------|-------------|
|  Stop |  Stop | | |
|  Play / Pause |  Play | | |
|  Play / Pause |  Pause | | |
|  << |  << | | |
|  >> |  >> | | |
|  << |  << | | |
|  >> |  >> | | |
|  --- |  Shift + 1 | | |
|  --- |  Shift + 2 | | |
|  --- |  Shift + 3 | | |
|  Red |  Red | | |
|  Green |  Green | | |
|  Yellow |  Yellow | | |
|  Blue |  Blue | | |
| | | | |
| | | | |
| | | | |

