







































































Original		Replacement		Original		Replacement	
	Power		Power		List		List
	Mute		Mute		PR +		Ch +
	1		1		PR -		Ch -
	2		2		Up		Up
	3		3		Left		Left
	4		4		OK		Ok
	5		5		Right		Right
	6		6		Down		Down
	7		7		Menu		Menu
	8		8		Exit		Exit
	9		9		FAV		Pre Ch
	0		0		EPG		Guide
	Info		Info		TV		TV/R
	Recall		Back		I / II		Dual
	Vol +		Vol +		PSM		Format
	Vol -		Vol -		SSM		Shift + Dual
	Input		AV		ARC		Options





	Original	Replacement		Original	Replacement
	Sleep	Sleep			
	Text	Text			
	Size	Eject			
	Reveal	Smart			
	Page +	Shift + Ch +			
	Page -	Shift + Ch -			
	Index	Shift + Info			
	Hold	Stop			
	S.Page	Subt			
	Red	Red			
	Green	Green			
	Yellow	Yellow			
	Blue	Blue			

