







































































Original		Replacement		Original		Replacement	
	Power		Power		P-		CH- / Page-
	Source		AV / Input / RDS		Vol+		Vol+
	1		1		Vol-		Vol-
	2		2		OK		OK
	3		3		Up		Up
	4		4		Down		Down
	5		5		Right		Right
	6		6		Left		Left
	7		7		Menu		Menu / Home
	8		8		Q.Menu		D.Menu / Top
	9		9		Exit		Exit / Cancel / Clear
	0		0		Media		Display / Media
	Recall		Shift + Back / Return		Back		Back / Return
	Mute		Mute / Dimmer		Guide		Guide / EPG / -/-
	TV		TV/Radio /		FAV		Fav / Marker / PC
	i		Info / Angle		[≡]/Text		Text / Goto
	P+		CH+ / Page+		Netflix		Smart / List





Original	Replacement	Original	Replacement
	www		Shift + Smart / List
	Lang		Audio / Lang I/II
	Red		Red / Netflix / Search
	Green		Green / APP / Repeat
	[≡]...		Sound / Title
	[-O-]		Picture / Format
	Yellow		Yellow / YouTube / Repeat
	Blue		Blue / Prime Video / Random
	Play		Play / Slow
	Pause		Pause / Step / Freeze
	>>		>> / Tune+
	<<		<< / Tune-
	Rec		Rec / Rec Mode
	Stop		Stop / Hold

