







































































Original	Replacement	Original	Replacement
 Power	 Power	 Right / V +	 Vol +
 Red / F1	 Red	 Left / V-	 Left
 Green / F2	 Green	 Left / V-	 Vol -
 Yellow / F3	 Yellow	 OK	 Ok
 Blue / F4	 Blue	 TV / Radio	 TV/R
 A - B	 AV	 Subtitle	 Subt
 EPG	 Guide	 Recall	 Back
 Text	 Text	 FAV	 Pre Ch
 Exit	 Exit	 1	 1
 Menu	 Menu	 2	 2
 Info	 Info	 3	 3
 Mute	 Mute	 4	 4
 Up / CH +	 Up	 5	 5
 Up / CH +	 Ch +	 6	 6
 Down / CH -	 Down	 7	 7
 Down / CH -	 Ch -	 8	 8
 Right / V +	 Right	 9	 9





Original	Replacement	Original	Replacement
0	0		

