



Original	Replacement
 Power	 Power
 1	 1
 2	 2
 3	 3
 4	 4
 5	 5
 6	 6
 7	 7
 8	 8
 9	 9
 0	 0
 Recall	 Back
 Still	 Pause
 TV / Input	 AV
 Multimedia	 Media
 Zoom -	 Shift + Down
 Zoom +	 Shift + Up

Original	Replacement
 Up / PR +	 Up
 Up / PR +	 Ch +
 Down / PR -	 Down
 Down / PR -	 Ch -
 Right / Vol +	 Right
 Right / Vol +	 Vol +
 Left / Vol -	 Left
 Left / Vol -	 Vol -
 Menu	 Menu
 Menu	 Ok
 Prev PR	 Pre Ch
 Screen Size	 3D
 Mute	 Mute
 Sleep	 Sleep
 [≡]	 Text
 [≡?]	 Smart
 [≡X]	 Exit

























































Original	Replacement	Original	Replacement
 [≡⇕]	 Eject		
 [≡●]	 TV/R		
 [≡□]	 Stop		
 Pic Mode / [≡≡]	 Format		
 Sound Mode / [≡≡]	 Dual		
 Red	 Red		
 Green	 Green		
 Yellow	 Yellow		
 Blue / I-II	 Blue		
 Blue / I-II	 Shift + Dual		






Original		Replacement		Original		Replacement	
	Power		Power		Menu		Ok
	1		1		<< FR / Slow		<<
	2		2		Play		Play
	3		3		>> FF / Slow		>>
	4		4		Stop		Stop
	5		5		I<< Prev		I<<
	6		6		Open / Close		Eject
	7		7		>>I Next		>>I
	8		8		Pause		Pause
	9		9				
	0		0				
	TV / Input		AV				
	Up / PR +		Up				
	Up / PR +		Ch +				
	Down / PR -		Down				
	Down / PR -		Ch -				
	Menu		Menu				





Original		Replacement	
	Power		Power
	1		1
	2		2
	3		3
	4		4
	5		5
	6		6
	7		7
	8		8
	9		9
	0		0
	Up / PR +		Up
	Up / PR +		Ch +
	Down / PR -		Down
	Menu		Ok
	Down / PR -		Ch -
	Menu		Menu

Original		Replacement	
	Red		Red
	Green		Green
	Yellow		Yellow
	Blue / I-II		Blue
	Blue / I-II		Dual

