
































































Original		Replacement		Original		Replacement	
	Power		Power		Smart Picture		Format
	⊖		Sleep		Menu		Menu
	Exit		Exit		Text / OK		Ok
	I-II		Dual		Text / OK		Text
	I.S.		Smart		Up		Up
	[i+]		Info		Left		Left
	1		1		Right		Right
	2		2		Down		Down
	3		3		Vol +		Vol +
	4		4		Vol -		Vol -
	5		5		Mute		Mute
	6		6		P +		Ch +
	7		7		P -		Ch -
	8		8		Red / Rec		Red
	9		9		Red / Rec		Rec
	0		0		Green / <<		Green
	Smart Audio		Shift + Dual		Green / <<		<<





Original		Replacement		Original		Replacement	
	Yellow / Stop		Yellow				
	Yellow / Stop		Stop				
	Blue / Play		Blue				
	Blue / Play		Play				
	[X]	+	Shift + Exit				
	[♦] / Ⓞ		3D				
	[□] / >>>	+	Shift + Stop				
	[□] / >>>		>>>				
	[/≡]	+	Shift + Text				
	[?]		TV/R				
	[≡i]		Guide				

