

















































	Original	Replacement		Original	Replacement
	Power		Power		>> FF
	Mode		Smart		I< / Page-
	Menu		Menu		I< / Page-
	Info		Info		>I / Page+
	Up		Up		>I / Page+
	Left		Left		Quality
	OK		Ok		Disk Info
	Right		Right		Delete
	Down		Down		Slow
	Recall		Pre Ch		F1
	Back		Back		F2
	Rec		Rec		F3
	Media		Media		
	Play		Play		
	Pause		Pause		
	<< REW		<<		
	Stop		Stop		

