



















Original	Replacement
 Power	 Power
 Source	 AV
 1	 1
 2	 2
 3	 3
 4	 4
 5	 5
 6	 6
 7	 7
 8	 8
 9	 9
 0	 0
 [S]	 Guide
 [-o-]	 Pre Ch
 Vol+	 Vol +
 Vol-	 Vol -
 Mute	 Mute

Original	Replacement
 CMS	 Smart
 P+	 Ch +
 P-	 Ch -
 Menu	 Menu
 Q.Menu	 D. Menu
 Exit	 Exit
 Back	 Back
 Up	 Up
 Down	 Down
 Right	 Right
 Left	 Left
 OK	 Ok
 List	 List
 Subt	 Subt
 Internet	 Media
 Audio	 Dual
 Format	 Format





Original		Replacement		Original	Replacement
	[^^]		Text		
	Red		Red		
	Green		Green		
	Yellow		Yellow		
	Blue		Blue		
	[≡^']		3D		
	*		Options		
	i		Info		
	<<		<<		
	Pause		Pause		
	>>		>>		
	Play		Play		
	Stop		Stop		
	Music/Photo/Video		TV/R		

