



Original	Replacement	Original	Replacement
	Power		Power
	Mute		Mute
	1		1
	2		2
	3		3
	4		4
	5		5
	6		6
	7		7
	8		8
	9		9
	0		0
	-/--		Guide
	Recall		Back
	Vol+		Vol +
	Vol-		Vol -
	Nicam		Dual
	Sleep		Sleep
	Display		Info
	CH+		Ch +
	CH-		Ch -
	Up		Up
	Left		Left
	OK		Ok
	Right		Right
	Down		Down
	Aspect		Format
	Source		AV
	P.Mode		Shift + Format
	S.Mode		Shift + Dual
	Exit		Exit
	Menu		Menu
	Media		Media
	Play / Pause		Play





Original	Replacement
Play / Pause	Pause
I<<	I<<
>>I	>>I
Rec	Rec
Stop / Hold	Stop
<< / Index	<<
>> / Size	>>
Text	Text
FAV	Pre Ch
FAV-	Shift + Down
FAV+	Shift + Up
Reveal	Smart
Cancel	Shift + Exit
Subpage	Shift + Subt
Subtitle	Subt
Red / TV/Radio	Red
Green	Green

Original	Replacement
Yellow	Yellow
Blue	Blue

