



















































	Original	Replacement		Original	Replacement
	Power		Power		Angle/TTX
	Goto		Back		Text
	Mute		Mute		Dual
	Source		AV		PBC/Scan
	1		1		Title
	2		2		Stop
	3		3		Play
	4		4		Pause
	5		5		Mode
	6		6		Setup
	7		7		Up
	8		8		Down
	9		9		Right
	0		0		Left
	10+		Pre Ch		Enter
	Step		Smart		Yellow/Zoom
	Subtitle		Subt		Red/Menu
					Green





Original	Replacement
 Blue	 Blue
 I<<	 I<<
 >>I	 >>I
 TV/Radio	 TV/R
 Repeat/Del	 +  Shift + Text
 Pro/EPG	 Guide
 Display	 Info
 <</FAV	 <<
 >>/Prot	 >>

Original	Replacement

