







































































|   | Original         | Replacement   |   | Original         | Replacement   |
|---|------------------|---|---|------------------|---|
|    | Power VCR        |  Power   |    | Tracking/V-Lock- |  Ch -    |
|    | Up               |  Up      |    | 1                |  1       |
|    | Down             |  Down    |    | 2                |  2       |
|    | Right            |  Right   |    | 3                |  3       |
|    | Left             |  Left    |    | 4                |  4       |
|    | Play             |  Play    |    | 5                |  5       |
|    | Stop             |  Stop    |    | 6                |  6       |
|    | >>               |  >>      |    | 7                |  7       |
|    | <<               |  <<      |    | 8                |  8       |
|   | Pause/Slow       |  Pause  |   | 9                |  9      |
|  | Rec/OTR          |  Rec   |  | 0                |  0     |
|  | Display          |  Info  |  | -/--             |  Guide |
|  | Zero Stop        |  Smart |  | Input Select     |  AV    |
|  | Jog/Shuttle On   |  Media |  | Vol+             |  Vol + |
|  | I<< Index        |  I<<   |  | Vol-             |  Vol - |
|  | >>I Index        |  >>I   |  | OSD              |  Back  |
|  | Tracking/V-Lock+ |  CH +  |  | Audio Out        |  Dual  |







































|  | Original         | Replacement      |  | Original      | Replacement       |
|--|------------------|------------------|--|---------------|-------------------|
|  | Tv/AV            | Pre Ch           |  | Nothing 1     | +  Shift + AV     |
|  | TV CH+           | +  Shift + Ch +  |  | Nothing 2     | +  Shift + Format |
|  | TV CH-           | +  Shift + Ch -  |  | Direct Tv Rec | Options           |
|  | Power Tv         | +  Shift + Power |  | AV Link       | Text              |
|  | << Wheel         | +  Shift + Left  |  | Jog/Shuttle ▲ | +  Shift + Media  |
|  | Wheel >>         | +  Shift + Right |  |               |                   |
|  | Central Wheel >> | +  Shift + Up    |  |               |                   |
|  | << Central Wheel | +  Shift + Down  |  |               |                   |
|  | Reset            | TV/R             |  |               |                   |
|  | Menu             | Menu             |  |               |                   |
|  | Exit             | Exit             |  |               |                   |
|  | Store            | 3D               |  |               |                   |
|  | PDC/VPS          | Blue             |  |               |                   |
|  | SP/LP            | Format           |  |               |                   |
|  | Timer Rec        | Red              |  |               |                   |
|  | Check            | Green            |  |               |                   |
|  | Transmit         | Yellow           |  |               |                   |









































































|   | Original      | Replacement   | Original | Replacement |
|---|---------------|---|----------|-------------|
|    | Power         |    |          |             |
|    | Direct Tv Rec |    |          |             |
|    | CH+           |    |          |             |
|    | CH-           |    |          |             |
|    | 1             |    |          |             |
|    | 2             |    |          |             |
|    | 3             |    |          |             |
|    | 4             |    |          |             |
|    | 5             |    |          |             |
|    | 6             |    |          |             |
|   | 7             |   |          |             |
|  | 8             |  |          |             |
|  | 9             |  |          |             |
|  | 0             |  |          |             |
|  | -/--          |  |          |             |
|  | Vol+          |  |          |             |
|  | Vol-          |  |          |             |





|   | Original       | Replacement   |   | Original         | Replacement  |
|---|----------------|---|---|------------------|--|
|    | Power VCR      |  Power           |    | Index >>I        |  >>I    |
|    | Up             |  Up              |    | Tracking/V.Lock+ |  Ch +   |
|    | Down           |  Down            |    | Tracking/V.Lock- |  Ch -   |
|    | Right          |  Right           |    | OSD              |  Back   |
|    | Left           |  Left            |    | Audio Out        |  Dual   |
|    | Play           |  Play            |    | Input Select     |  AV     |
|    | Stop           |  Stop            |    | Tv/AV            |  Pre Ch |
|    | >>             |  >>              |    | 1                |  1      |
|    | <<             |  <<              |    | 2                |  2      |
|   | Pause/Slow     |  Pause          |   | 3                |  3     |
|  | Rec/OTR        |  Rec           |  | 4                |  4    |
|  | Display        |  Info          |  | 5                |  5    |
|  | Reset          |  TV/R          |  | 6                |  6    |
|  | Zero Stop      |  Smart         |  | 7                |  7    |
|  | Jog/Shuttle On |  Media         |  | 8                |  8    |
|  | Jog/Shuttle ▲  |  Shift + Media |  | 9                |  9    |
|  | I<< Index      |  I<<           |  | 0                |  0    |





| Original      | Replacement    | Original | Replacement |
|---------------|----------------|----------|-------------|
| -/--          | Guide          | Check    | Green       |
| Vol+          | Vol +          |          |             |
| Vol-          | Vol -          |          |             |
| Tv CH+        | Shift + Ch +   |          |             |
| Tv CH-        | Shift + Ch -   |          |             |
| Direct Tv Rec | Options        |          |             |
| AV Link       | Text           |          |             |
| Menu          | Menu           |          |             |
| Exit          | Exit           |          |             |
| Store         | 3D             |          |             |
| Nothing 1     | Shift + AV     |          |             |
| Nothing 2     | Shift + Format |          |             |
| SP/LP         | Format         |          |             |
| PDC/VPS       | Blue           |          |             |
| Transmit      | Yellow         |          |             |
| Power Tv      | Shift + Power  |          |             |
| Timer Rec     | Red            |          |             |

