




































































| Original  | Replacement  | Original  | Replacement           |
|---|--------------|---|-----------------------|
|      | Power        |      | Power                 |
|      | 1            |      | 1                     |
|      | 2            |      | 2                     |
|      | 3            |      | 3                     |
|      | 4            |      | 4                     |
|      | 5            |      | 5                     |
|      | 6            |      | 6                     |
|      | 7            |      | 7                     |
|      | 8            |      | 8                     |
|     | 9            |     | 9                     |
|    | 0            |    | 0                     |
|    | P+           |    | CH+ / Page+           |
|    | P-           |    | CH- / Page-           |
|    | Vol+         |    | Vol+                  |
|    | Vol-         |    | Vol-                  |
|    | Open/Close   |    | Eject / Surround      |
|    | Guide        |    | Guide / EPG / -/--    |
|    | Mute         |    | Mute / Dimmer         |
|    | I<<          |    | I<< / Preset-         |
|    | >>I          |    | >>I / Preset+         |
|    | <<           |    | << / Tune-            |
|    | >>           |    | >> / Tune+            |
|    | Stop         |    | Stop / Hold           |
|    | Pause        |    | Pause / Step / Freeze |
|    | Play         |    | Play / Slow           |
|    | Info         |    | Info / Angle          |
|   | Exit         |   | Exit / Cancel / Clear |
|  | Media Center |  | Display / Media       |
|  | Up           |  | Up                    |
|  | Home Menu    |  | Menu / Home           |
|  | Pop-Up Menu  |  | D.Menu / Top          |
|  | Down         |  | Down                  |
|  | Left         |  | Left                  |
|  | Right        |  | Right                 |





| Original | Replacement                 |
|----------|-----------------------------|
|          | OK                          |
|          | Setup / OPT /               |
|          | Back / Return               |
|          | Red / Netflix / Search      |
|          | Green / APP / Repeat        |
|          | Yellow / YouTube / Repeat   |
|          | Blue / Prime Video / Random |
|          | Rec / Rec Mode              |
|          | Text / Goto                 |
|          | Subtitle / EQ               |
|          | TV/Radio /                  |
|          | Sleep / Timer               |
|          | Smart / List                |
|          | +  Shift + Display / Media  |
|          | Sound / Title               |
|          | Picture / Format            |
|          | Audio / Lang I/II           |

| Original | Replacement                 |
|----------|-----------------------------|
|          | Fav / Marker / PC           |
|          | AV / Input / RDS            |
|          | +  Shift + Power            |
|          | +  Shift + Vol+             |
|          | +  Shift + Vol-             |
|          | +  Shift + CH+ /            |
|          | +  Shift + CH- /            |
|          | +  Shift + AV / Input / RDS |
|          |                             |
|          |                             |
|          |                             |
|          |                             |
|          |                             |
|          |                             |
|          |                             |
|          |                             |
|          |                             |
|          |                             |
|          |                             |
|          |                             |
|          |                             |

