







































































Original		Replacement		Original		Replacement	
	Power		Power		4		4
	Mute		Mute		5		5
	TV / AV		AV		6		6
	Menu		Menu		7		7
	Sleep		Sleep		8		8
	Up / PR+		Up		9		9
	Up / PR+		Ch +		0		0
	Down / PR-		Down		APC		I<<
	Down / PR-		Ch -		ASC		<<
	Right / Vol+		Right		ARC		>>
	Right / Vol+		Vol +		PIP		Smart
	Left / Vol-		Left		Review		Info
	Left / Vol-		Vol -		MTS		Dual
	OK		Ok		Multi PIP		Format
	1		1		Multimedia		Media
	2		2		Red / PIP CH+		Red
	3		3		Green / PIP CH-		Green





Original	Replacement	Original	Replacement
Yellow / PIP SWAP	Yellow		
Blue / PIP Input	Blue		
Text	Text		
Mode	Options		
Size / PIP Size	Eject		
Mix	TV/R		
Sub Page	Subt		
Index	Shift + Info		
Reveal	D. Menu		
Hold / PIP Still	Stop		
Update / PIP Position	Guide		

