

























































Original	Replacement	Original	Replacement
 Power	 Power	 Up	 Ch +
 1	 1	 Video	 Format
 2	 2	 Audio	 Dual
 3	 3	 Favor Down	 Left
 4	 4	 Favor Down	 Vol -
 5	 5	 Favor Up	 Right
 6	 6	 Favor Up	 Vol +
 7	 7	 Mute	 Mute
 8	 8	 LNB	 Smart
 9	 9	 F.Set	 Ok
 0	 0		
 Sleep	 Sleep		
 Lock	 Info		
 Store	 Media		
 Down	 Down		
 Down	 Ch -		
 Up	 Up		

