













































































Original	Replacement	Original	Replacement
	Power		Power
	Mode/Auto		Smart
	Plus/Pixel		Media
	FAV		Shift + Pre Ch
	Sleep		Sleep
	Red/Demo		Red
	Green		Green
	Yellow		Yellow
	Blue		Blue
	Menu/Exit		Menu
	Source		AV
	Options		Options
	Up		Up
	Down		Down
	Right		Right
	Left		Left
	OK		Ok
	Back		Back
	Info		Info
	<<		<<
	Play		Play
	Pause		Pause
	>>		>>
	Stop		Stop
	Rec		Rec
	Vol+		Vol +
	Vol-		Vol -
	Mute		Mute
	Format		Format
	CH+		Ch +
	CH-		Ch -
	1		1
	2		2
	3		3





Original		Replacement		Original		Replacement	
	4		4				
	5		5				
	6		6				
	7		7				
	8		8				
	9		9				
	0		0				
	Prev CH		Pre Ch				
	.		Guide				

