























































Original		Replacement		Original		Replacement	
	Power		Power		OK/List		Ok
	Mute		Mute		Menu		Menu
	1		1		Exit		Exit
	2		2		Guide		Guide
	3		3		Recall		Back
	4		4		Green/FAV		Green
	5		5		Red/Audio/Subtitl		Red
	6		6		Yellow/UHF		Yellow
	7		7		Blue/i		Blue
	8		8				
	9		9				
	0		0				
	Tv/Radio		TV/R				
	Up		Up				
	Down		Down				
	Right		Right				
	Left		Left				

