

















































Original	Replacement
	 Power
	 Mute
	 Dual
	 Sleep
	 Format
	 AV
	 Menu
	 Exit
	 Up
	 Ch +
	 Left
	 Vol -
	 Ok
	 Vol +
	 Right
	 Ch -
	 Down

Original	Replacement
	 Guide
	 Info
	 List
	 Rec
	 Smart
	 Shift + Ch -
	 Shift + Ch +
	 Stop
	 Play
	 Pause
	 Shift + Pause
	 Red
	 <<
	 TV/R
	 Green
	 >>
	 Pre Ch





Original	Replacement
 Yellow / SAT / <II	 Yellow
 Yellow / SAT / <II	 Media
 Blue /   > / +/-	 Blue
 I<<	 I<<
 >>I	 >>I
 Repeat T1/T2	 SHIFT +  REPEAT TEXT Shift + Text
 White / A-B	 3D 3D
 Subtitle	 AD SUBT Subt
 Text	 REPEAT TEXT Text
 Dual screen	 SETTINGS OPT Options
 Zoom	 ZOOM Eject
 1*?	 1 1
 2ABC	 2 2
 3DEF	 3 3
 4GHI	 4 4
 5JKL	 5 5
 6MNO	 6 6

Original	Replacement
 7 PORS 7	 7 7
 8 TUV 8	 8 8
 9 WXYZ 9	 9 9
 0 0	 0 0
 ?	 E-MANUAL D.MENU D. Menu
 Recall	 RETURN BACK Back

