






































































Original	Replacement	Original	Replacement
	Power		Power
	AV Mode		Shift + AV
	Radio		TV/R
	TruSurround		List
	OPC		Media
	DTV		Smart
	1		1
	2		2
	3		3
	4		4
	5		5
	6		6
	7		7
	8		8
	9		9
	0		0
	Recall		Pre Ch
	Source		AV
	P+		Ch +
	P-		Ch -
	Vol+		Vol +
	Vol-		Vol -
	Mute		Mute
	[<>]		Format
	▼/O)I/II/I+II		Dual
	[i+]		Info
	Sleep		Sleep
	EPG		Guide
	ESG		Options
	DTV Menu		D. Menu
	[≡]		Text
	Menu		Menu
	End		Exit
	Return		Back





Original	Replacement
Up	Up
Down	Down
Right	Right
Left	Left
OK	Ok
[≡?]	3D
[≡+]	Eject
[...]	Subt
[≡o]	Shift + 3D
Red	Red
Green	Green
Yellow	Yellow
Blue	Blue

Original	Replacement

