








































Original		Replacement		Original		Replacement	
	Power		Power		Play		Play
	Night		Sleep		Pause		Pause
	Mute		Mute		>>		>>
	HDMI 1		1				
	HDMI 2		2				
	TV		TV/R				
	Bluetooth		Smart				
	Vol+		Vol +				
	Vol-		Vol -				
	Bass+		Up				
	Bass-		Down				
	Voice+		Ch +				
	Voice-		Ch -				
	Movies		Options				
	Sports		Subt				
	Music		Dual				
	<<		<<				

