







































































Original	Replacement
 Power	 Power
 Open/Close	 Eject
 1	 1
 2	 2
 3	 3
 4	 4
 5	 5
 6	 6
 7	 7
 8	 8
 9	 9
 0	 0
 Clear	 Exit
 <<	 <<
 >>	 >>
 I<<	 I<<
 >>I	 >>I

Original	Replacement
 Play	 Play
 Pause/Step	 Pause
 Stop	 Stop
 DVD Menu	 D. Menu
 Return	 Back
 Display	 Info
 O)/Audio	 Dual
 [...]/Subtitle	 Subt
 Setup	 Options
 Marker	 Media
 Search	 TV/R
 Camera/Angle	 Smart
 Program	 Sleep
 Zoom	 Shift + Eject
 Repeat	 Text
 A-B	 Format
 Random	 3D



