














































| Original  | Replacement   | Original   | Replacement   |
|---|---|--|---|
|  Standby         |  Power                       |  >>I/Subpage            |  >>I / Preset+         |
|  Source          |  AV / Input / RDS            |  Menu                   |  Menu / Home           |
|  Red             |  Red / Netflix / Search      |  Up                     |  Up                    |
|  Green           |  Green / APP / Repeat        |  Exit                   |  Exit / Cancel / Clear |
|  Yellow          |  Yellow / YouTube / Repeat   |  Left                   |  Left                  |
|  Blue            |  Blue / Prime Video / Random |  Enter                  |  OK                    |
|  e               |  Info / Angle                |  Right                  |  Right                 |
|  Mouse           |  Smart / List                |  Play/Pause / Timeshift |  Pause / Step / Freeze |
|  Home            |  Shift + Menu /              |  Play/Pause / Timeshift |  Play / Slow           |
|  TXT             |  Text / Goto                 |  Down                   |  Down                  |
|  Mix/FAV.List   |  Fav / Marker / PC          |  Stop / EPG            |  Stop / Hold          |
|  Size/Subtitle |  Subtitle / EQ             |  Vol+                 |  Vol+                |
|  Cancel/Audio  |  Audio / Lang I/II         |  Mute                 |  Mute / Dimmer       |
|  Record        |  Rec / Rec Mode            |  CH+                  |  CH+ / Page+         |
|  <</Index      |  << / Tune-                |  Vol-                 |  Vol-                |
|  >>/Hold       |  >> / Tune+                |  Tv/Radio             |  TV/Radio /          |
|  I<</Reveal    |  I<< / Preset-             |  CH-                  |  CH- / Page-         |



