






Original	Replacement
 Power	 Power
 Source Search	 Source
 Computer	 Comp / Video
 HDMI/Video	 Shift + Comp / Video
 Lan	 Volt / Focus
 USB	 3D / Invert
 Menu	 Menu
 Auto	 Auto
 Aspect	 Eco / Aspect
 A/V Mute	 Blank / Mute
 User	 Shift + Up
 Color Mode	 Mode
 Pen Mode	 Shift + Source
 Link Menu	 Shift + Menu
 Pointer	 Shift + Down
 Freeze	 Freeze / Timer
 Esc	 Shift + Mode

Original	Replacement
 Home	 Shift + Power
 Split	 Help / Info
 Up	 Up
 Down	 Down
 Right	 Right
 Left	 Left
 Enter	 Enter
 Vol+	 Vol + / Page +
 Vol-	 Vol - / Page -
 E-Zoom+	 + / Play
 E-Zoom-	 - / Stop
 Page Up	 Shift + Vol + / Page +
 Page Down	 Shift + Vol - / Page -
 1	 Shift + Freeze / Timer
 2	 Shift + + / Play
 3	 Shift + Volt / Focus
 4	 Shift + - / Stop





Original		Replacement		Original		Replacement	
5	5	Shift + Info Help	Shift + Help /				
6	6	Shift + Aspect Eco	Shift + Eco / Aspect				
7	7	Shift + Invert 3D	Shift + 3D /				
8	8	Shift + Mute Blank	Shift + Blank / Mute				
9	9	Shift + [Right Arrow]	Shift + Right				
0	0	Shift + Auto	Shift + Auto				
ID	ID	Shift + [Left Arrow]	Shift + Left				

