







































































Original		Replacement		Original		Replacement	
	Power		Power		Menu		Menu
	Source		AV		Ch +		Ch +
	Mute		Mute		Ch -		Ch -
	1		1		Play		Play
	2		2		Pause		Pause
	3		3		Stop		Stop
	4		4		Up		Up
	5		5		Down		Down
	6		6		Right		Right
	7		7		Left		Left
	8		8		Ok		Ok
	9		9		Red/Image		Red
	0		0		Green/Audio		Green
	-/--		Guide		Yellow/Sleep		Yellow
	Recall		Back		Blue/Freeze		Blue
	Vol +		Vol +		←		Media
	Vol -		Vol -		→		Smart



