



















































































Original	Replacement	Original	Replacement
 Standby	 Power	 TV/Radio	 TV/R
 Source	 AV	 Display	 Info
 1	 1	 Up	 Up
 2	 2	 Left	 Left
 3	 3	 OK	 Ok
 4	 4	 Right	 Right
 5	 5	 Down	 Down
 6	 6	 Menu	 Menu
 7	 7	 Exit	 Exit
 8	 8	 Mute	 Mute
 9	 9	 EPG	 Guide
 0	 0	 Home	 Smart
 Fav	 Pre Ch	 Vol+	 Vol +
 Recall	 Back	 Vol-	 Vol -
 P.Mode	 Shift + Format	 CH+	 Ch +
 S.Mode	 Shift + Dual	 CH--	 Ch -
 Sleep	 Sleep	 Rec	 Rec





Original	Replacement
 T.Shift	 Media
 Audio	 Dual
 Size / Aspect	 Format
 Text	 Text
 Hold	 Shift + Stop
 Reveal	 Shift + Pause
 Mouse	 Options
 Play / Pause	 Play
 Play / Pause	 Pause
 Stop	 Stop
 Subtitle	 Subt
 Index / Reclist	 List
 <<	 <<
 >>	 >>
 I<< / Subpage	 I<<
 >>I / Mix	 >>I
 Red	 Red

Original	Replacement
 Green	 Green
 Yellow	 Yellow
 Blue	 Blue

