



| Original | | Replacement | | Original | | Replacement | |
|---|----------|---|--------|---|-------|---|--------|
|  | Power |  | Power |  | EPG |  | Guide |
|  | Mute |  | Mute |  | Menu |  | Menu |
|  | Red |  | Red |  | Info |  | Info |
|  | Green |  | Green |  | Up |  | Up |
|  | Yellow |  | Yellow |  | Left |  | Left |
|  | Blue |  | Blue |  | OK |  | Ok |
|  | << |  | << |  | Right |  | Right |
|  | >> |  | >> |  | Down |  | Down |
|  | l<< |  | l<< |  | FAV |  | Pre Ch |
|  | >>l |  | >>l |  | Exit |  | Exit |
|  | Play |  | Play |  | Vol+ |  | Vol + |
|  | Pause |  | Pause |  | Vol- |  | Vol - |
|  | Stop |  | Stop |  | Rec |  | Rec |
|  | Media |  | Media |  | USB |  | Smart |
|  | Subtitle |  | Subt |  | USB |  | AV |
|  | TTX |  | Text |  | CH+ |  | Ch + |
|  | Audio |  | Dual |  | CH- |  | Ch - |



