











































































Original		Replacement		Original		Replacement	
	Standby AV		Power		Green		Green
	Info		Info		Yellow		Yellow
	Direct Navigator		Smart		Blue		Blue
	Menu		Menu		Stop		Stop
	EPG		Guide		Pause		Pause
	Up		Up		Play		Play
	Down		Down		1		1
	Right		Right		2		2
	Left		Left		3		3
	OK		Ok		4		4
	Exit		Exit		5		5
	Prog/Check		Options		6		6
	Edit		Pre Ch		7		7
	Delete		Back		8		8
	<<		<<		9		9
	>>		>>		0		0
	Red		Red		Live		Media









































































Original	Replacement
 Tv/Radio	 TV/R
 Rec	 Rec
 Rec Pause	 Shift + Pause
 Display	 Shift + Info
 AV HDD+	 Vol +
 AV HDD-	 Vol -
 Skip	 AV
 Set Book Mark	 Subt
 Go Book Mark	 Shift + TV/R
 Timer Rec	 Text
 Replay	 Shift + Options
 Audio	 Dual
 Aspect	 Format
 Power Tv	 Shift + Power
 Tv/AV Tv	 Shift + AV
 CH+ TV	 Ch +
 CH- Tv	 Ch -

Original	Replacement
 Vol+ Tv	 Shift + Right
 Vol- Tv	 Shift + Left





Original		Replacement		Original		Replacement	
	Standby AV		Power		Green		Green
	Info		Info		Yellow		Yellow
	Direct Navigator		Smart		Blue		Blue
	Menu		Menu		Stop		Stop
	EPG		Guide		Pause		Pause
	Up		Up		Play		Play
	Down		Down		1		1
	Right		Right		2		2
	Left		Left		3		3
	OK		Ok		4		4
	Exit		Exit		5		5
	Prog/Check		Options		6		6
	Edit		Pre Ch		7		7
	Delete		Back		8		8
	<<		<<		9		9
	>>		>>		0		0
	Red		Red		Live		Media





	Original	Replacement		Replacement
	Tv/Radio		TV/R	
	Rec		Rec	
	Rec Pause		>>	
	Display	 + 	Shift + Info	
	AV HDD+		Vol +	
	AV HDD-		Vol -	
	Skip		AV	
	Set Book Mark		Subt	
	Go Book Mark	 + 	Shift + TV/R	
	Timer Rec		Text	
	Replay	 + 	Shift + Options	
	Audio		Dual	
	Aspect		Format	

	Original	Replacement		Replacement

