
























































	Original	Replacement		Original	Replacement
	Power		Power		SRS
	Source		AV		Smart
	1		1		Vol +
	2		2		Vol -
	3		3		Mute
	4		4		Ch +
	5		5		Ch -
	6		6		Menu
	7		7		Exit
	8		8		Up
	9		9		Down
	0		0		Right
	-/-		Guide		Left
	PRE-CH		Pre Ch		Enter
	TV		TV/R		[≡+]/PIP
	CH MGR		Media		[≡?]/Info
	Sleep		Sleep		TTX/MIX
					Red/P.Mode
					Red





Original	Replacement	Original	Replacement
Green/S.Mode	Green		
Yellow/Still	Yellow		
Blue/P.Size	Blue		
[≡◆]/Source	Format		
[≡◆]/Swap	Subt		
Size	Eject		
I/II/Dual	Dual		
Turbo	Options		
[+]/Position	List		
P up	>>I		
P Down	>>		

