







































































Original		Replacement		Original		Replacement	
	Power		Power		Aspect		3D
	Mute		Mute		CH +		Ch +
	1		1		CH -		Ch -
	2		2		Vol +		Vol +
	3		3		Vol -		Vol -
	4		4		Info		Info
	5		5		Nicam/A2 / Audio		Dual
	6		6		Auto		Smart
	7		7		P.Mode		Shift + Format
	8		8		Menu		Menu
	9		9		S.Mode		Shift + Dual
	0		0		Exit		Exit
	-/--		Guide		Up		Up
	Prev. Ch.		Pre Ch		Down		Down
	Sleep		Sleep		Right		Right
	Still		Options		Left		Left
	Source		AV		OK		Ok



