

























































	Original	Replacement		Original	Replacement
	Power		Power		1
	Mute		Mute		2
	Tv/AV		AV		3
	Multimedia		Media		4
	I/II		Dual		5
	List		List		6
	Q.View		Options		7
	Menu		Menu		8
	Up		Up		9
	Down		Down		0
	Right		Right		SSM
	Left		Left		Guide
	OK		Ok		Pre Ch
	PR+		Ch +		Sleep
	PR-		Ch -		Back
	Vol+		Vol +		Text
	Vol-		Vol -		[≡x]/Update
					[≡o]/Time
					Subt
					TV/R



