






























































Original	Replacement	Original	Replacement
 Power	 Power	 Blue / SMode	 Shift + Dual
 Mute	 Mute	 Blue / SMode	 Shift + Blue
 Exit	 Exit	 Up	 Up
 Text	 Text	 Left	 Left
 Audio I/II	 Dual	 Enter	 Ok
 Display	 Info	 Right	 Right
 Sleep	 Sleep	 Down	 Down
 P+	 Ch +	 1	 1
 P-	 Ch -	 2	 2
 V+	 Vol +	 3	 3
 V-	 Vol -	 4	 4
 Red / Source	 AV	 5	 5
 Red / Source	 Shift + Red	 6	 6
 Green / TV	 Menu	 7	 7
 Green / TV	 Shift + Green	 8	 8
 Yellow / PMode	 Format	 9	 9
 Yellow / PMode	 Shift + Yellow	 0	 0





Original	Replacement	Original	Replacement
 -/-	 +  Shift + Guide	 Stop / FAV -	 +  Shift + Left
 Recall	 Back	 << / FAV	 <<
 Red	 Red	 << / FAV	 Pre Ch
 Green	 Green	 >> / FAV+	 >>
 Yellow	 Yellow	 >> / FAV+	 +  Shift + Right
 Blue / Repeat	 Blue	 EPG	 Guide
 Blue / Repeat	 +  Shift + Text	 USB/SD	 Media
 Subtitle	 Subt	 Recorder	 Rec
 Pause/Play / Hold	 Play	 CH.List	 List
 Pause/Play / Hold	 Pause	 TV / Radio	 TV/R
 Size	 3D		
 Mix	 D. Menu		
 Reveal	 +  Shift + Info		
 TXT Index	 Eject		
 I<< / Subpage	 I<<		
 >>I / Lang	 >>I		
 Stop / FAV -	 Stop		

